





ClearUp BIO Addition Instructions




STEP 1

Add ClearUp BIO to wine/juice (>20°C).



STEP 2

Stir well until you have a homogenous suspension without any solids.



STEP 3

Add to tank and mix well.

Note: For addition to increase internal surface (NTU), please follow steps 1 to 3 only, then rack as usual following fermentation.



STEP 4

Allow contact time of up to 48hrs depending on application.



STEP 5

Then remove ClearUp BIO by racking or filtration (do not use a centrifuge).

Practical Application

For all applications it is important to ensure that ClearUp BIO is well suspended and well distributed in the wine.

Any bentonite-fining should be applied after the ClearUp BIO fining.

